

QUIK-CUTTER SOFTWARE UPDATES

The Quik-Cutter printer is now equipped with a feature that enables quieter printing. The following are changes that have been made to the standard software.

Under **M8 Form Thickness Control**, a new printhead impact force feature is added (see Table 1 for display values).

Changing this feature from low, medium or high will result in an Auto Form Gap being performed. The Adjust Form Gap feature value changes with each setting to the value listed in Table 1. The Low setting gives adequate print quality when using one or two-part forms. The Medium setting is adequate for up to four-part forms. The High setting represents the standard impact force and prints up to nine-part forms.

The "Whisper/" values (described in the following table) act in the same manner as the Quiet Mode Feature previously found under M4 Printer Control, with the addition of controllable impact force. For example, "Whisper/Low" causes unidirectional and half-speed printing with low printhead impact force.

To change any of these feature values refer to the User Manual, Chapter 4 *Features and Profiles*.

Table 1 Features

Printer Displays	Values	Description
Quiet/HIGH (Menu 8) Note: Use the Value [▲] or Value [▼] keys to scroll through the list.	Quiet/LOW	Prints one or two-part forms. Adj Form Gap defaults to 30
	Quiet/MEDIUM	Prints up to four-part forms. Adj. Form Gap defaults to 33
	Quiet/HIGH*	Prints up to nine-part forms. Adj. Form Gap defaults to 36
	Whisper/LOW	Prints unidirectional, one or two-part forms. Adj Form Gap defaults to 30
	Whisper/MEDIUM	Prints unidirectional, up to four-part forms. Adj. Form Gap defaults to 33
	Whisper/HIGH	Prints unidirectional, up to nine-part forms. Adj. Form Gap defaults to 36

*Default value

DPCL COMMANDS

This printer is also equipped with DPCL Emulation that allows downline programming capabilities.

The DPCL sequence for the Quiet/Whisper Impact feature outlined in the table is as follows:

ESC \$ \$ E 1 . E 3 3 : <n> . X . where <n> is 0 to 5

n = 0	Quiet/LOW
n = 1	Quiet/MEDIUM
n = 2	Quiet /HIGH - default value
n = 3	Whisper/LOW
n = 4	Whisper/MEDIUM
n = 5	Whisper/HIGH