

# TP2000 PAPER DRIVE BELT REPLACEMENT INSTRUCTIONS

## Tools Required:

No.2 Phillips screwdriver

## To Replace the Paper Drive Belt:

1. Verify that all replacement parts and tools are present.
2. Turn off the power switch, unplug the AC power cord, and disconnect all communication and interface cables.
3. Remove two #8-32 Phillips screws from the Top Cover, located in front on bottom side, then lift and lock the Cover in place by pushing down the Locking Hinge Bracket, located on the left and inside of Base Assembly.
4. Loosen two #8-32 Phillips screws and remove the Compression Spring on the Paper Belt Tension Bracket, located on the Right Endplate, then shift the bracket up all the way and tighten the left #8-32 screw to release the tension on the Paper Drive Belt. Remove the belt from the Pulley Hub and the Paper Motor Pulley.
5. Install the new Paper Drive Belt over both the Paper Motor Pulley and the Pulley Hub, and under the Idler Roller. Loosen the left #8-32 screw and insert the Compression spring on the Paper Belt Tension Bracket then tighten the two #8-32 Phillips screws from step 4.
6. Unlock (pull up on the Locking Hinge Bracket) and close the Top Cover then secure with the two #8-32 Phillips screws from step 3.
7. Reconnect all communication and interface cables, plug in the AC power cord and turn on the power switch.
8. Verify proper functionality by printing a self-test (*refer to the Operations and/or Maintenance Manuals if you need additional information*).

