

## ATB Printer Cabling Instructions

### Journey to DS242/Documax Itinerary Printer Cabling Instructions

1. Power off both the Journey printer and the itinerary printer.
2. Attach the connector labeled “ATTACH TO JOURNEY PRINTER ONLY” to the Journey Com 2 OUTPUT port.
3. Secure the connection with the screws on the connector.
4. Attach the connector labeled “ATTACH TO ITINERARY PRINTER ONLY” to the itinerary printer serial port. (On the DS242, use the 9 to 25 pin pigtail supplied with the DS242.
5. Secure the connection with the screws on the connector.
6. Power on the Journey printer.
7. Power on the itinerary printer.
8. Verify, on Journey, that the Baud Rate on COM 2 matches that of the itinerary printer.

